

IMPORTANT

- Recharge the work light every 3 months if it is not being used for a long time, or recharge it after used.
- Charge before use, although the battery is delivered in a charged state.
- It is advisable to use the unit from time to time in order to maintain the unit in good condition.
- Do not dispose of the unit into fire or dismantle it under any condition.
- Reverse charging is not acceptable.
- Do not short circuit the battery. Permanent damage to the battery may result.
- Never insert any foreign metallic objects into the charge jack of the work light.
- Never leave the unit in extremely high temperatures while charging.
- Use battery in extreme condition may affect the service life, such as extreme temperature, deep cycle, and extreme overcharged or over discharged.
- Battery should be stored in a cool and dry place.
- Be sure to use manufacturer's replacement parts.

Work Light

Installation Manual

liglo

IIFL1280LMW


OPERATION

LOW > HIGH > OFF
[Press OFF if stays at any mode over 10 seconds]
[Adjust the stand position for suitable lighting projection]


BATTERY POWER INDICATION

The LED indicators show battery power after work light is being turned on. When the battery power is low, please recharge the work light as soon as possible.

Charging Status Indicators



Battery Power Indicators



HOW TO RECHARGE

When the work light becomes noticeably dim, switch off the unit and recharge the work light as soon as possible.

Battery Type: Built-in 2 x 3.7V 2000mAh 18650 Li-ion Rechargeable Batteries
Charging Time: 6hrs

[Work light turns to about 5% brightness automatically when it is in charging status (with power connected)]

1. Open charge jack cover.
2. Connect the work light to your PC, or an approved USB adaptor, a solar panel, a portable power bank or any other charging device with an USB outlet, with the micro USB cable plugging to the input port.
3. The LED indicators will light up & flash one by one gradually to indicate the battery capacity is being charged.

NOTE

- Recharge the work light every 3 months if it is not being used for a long time, or recharge it after used.
- The rechargeable battery will reach full performance only after a few complete charging & discharging cycles.
- DO NOT leave the work light in charging status (with power connected) continuously for more than five days, as this may cause a reduction in battery efficacy.

